

# Instructivo de armado

## Mueble TV Aqua


Ref.22766











**AMBIENTE GOURMET.**  
**AMBIENTE LOFT.**

**AMBIENTE LIVING.**  
**CLUB HOUSE.**


# Assembly Instruction





Panel No	Panel Sizes	Quantity
1	1500*400*16	1
2	1500*400*16	1
3	268*399*16	1
4	268*399*16	1
5	268*399*16	1
6	268*362*16	1
7	268*379*16	1
8	350*100*16	1

Panel No	Panel Sizes	Quantity
9	264*368*16	1
10	352*375*16	1
11	278*735*5	1
12	278*735*5	1
13	350*80*12	1
14	350*80*12	1
15	304*80*12	1
16	348*314*5	1



# Fittings



A=20



B=20




C=20



D=28




E=8



F=1



G1=22




I3=2




J-1=4



H=1



J-2=2



L=4



O=8



P=8



N=1



J-3=1



U=2



V1=8




Z1=22









Z2=22


1




# 2



3




4







# 5




# 6



7




8




# 9


9-1




9-2




9-3




# 10




# 11




# 12




# 13




# 14



# 15



# 卢克斯电视柜邮购包装图



Panel No		Panel Sizes	Quantity
17	护角	50*50*50	8
18	泡沫	1500*410*10	2
19	泡沫	450*100*40	2
20	泡沫	1500*100*20	2
21	泡沫	80*58*15	1
22	泡沫	400*21*15	1
23	泡沫	714*55*15	1
24	泡沫	100*29*15	1
25	泡沫	400*92*15	1
26	泡沫	642*32*15	1

Panel No		Panel Sizes	Quantity
27	泡沫	80*35*10	1
28	泡沫	735*42*10	1
29	泡沫	400*421*5	1
30	泡沫	314*52*5	1
31	泡沫	380*160*50	2
32	纸盒	内径1590*460*110	1